



the ERIE Tool Works company

ENGLISH Wheel Kit - Dual

IMPORTANT For Parts & Service **DO NOT RETURN** the product to the store
Contact our customer service team for assembly questions, parts or service

TEL: 866-316-3743

service@ETWcompany.com


ERIEtoolworkscompany.com

SAFETY

- NEVER over inflate an Air Tire
- NEVER use an air compressor to inflate an Air Tire
- NEVER allow a person to climb on, or ride in, a wheelbarrow

TOOLS & TIPS

- Confirm you have all the parts and hardware
- Do not fully tighten bolts** until final assembly is complete



1. Slide each spacer onto the axle.
2. Slide all bearings and washers onto the axle, excluding the last large washer cap.
3. Slide each wheel onto the axle followed by the washer cap and cotter pin.
4. With both wheels on, slide the u-bolts over the axle.
5. Align and insert the u-bolts into the handles. Secure with nuts and washers. The axle boxings are not require between the axle and handle of the wheelbarrow.

