



the ERIE Tool Works company

ENGLISH  
SE163

**IMPORTANT** For Parts & Service **DO NOT RETURN** the product to the store  
Contact our customer service team for assembly questions, parts or service

TEL: 866-316-3743

service@ETWcompany.com


**SAFETY**

- NEVER over inflate an Air Tire
- NEVER use an air compressor to inflate an Air Tire
- NEVER allow a person to climb on, or ride in, a wheelbarrow

**TOOLS & TIPS**

- Confirm you have all the parts and hardware
- Do not fully tighten bolts** until final assembly is complete
- Tools not included 1) flat screw driver 2) adjustable wrench

**ASSEMBLY**



**PARTS LIST**

Qty	Description		
1	Tray		
2	Handles		
2	Legs		
1	Leg Brace		
2	Tray Braces		
1	Long Cross Brace		
1	Short Cross Brace		
1	I - Beam		
2	Axle Brackets		
2	Axle Plates		
1	Axle		
1	Front Guard		
2	Wheels		
2	Wheel Spacers		
1	Hardware Package		
Hardware Contents :			
all hardware includes bolts & washers			
4 - 3"	4 - 2-1/6"	2 - Cotter Pins	
4 - 2-3/4"	6 - 3/4"	6 - Large Washers	

**INSTRUCTIONS**

- (1) Assemble the I-Beam to the Long Cross Brace and Short Cross Brace using 2 - 3/4" bolts. Bolt heads must be facing the bottom of the Tray when installed.
- (2) Align the Tray on the Handles making sure to align all holes.
- (3) Insert 4 - 3" bolts through a Large Washer and then the holes on the bottom of the Tray and through the assembled I-Beam noted in Step 1 with the Long Cross Brace at the rear of the Tray. Attach a Handle and Leg over the bolts on one side of the Tray and loosely tighten each bolt with a washer and nut. Repeat for the other side.
- (4) Attach the Leg Brace to the Legs using 2 - 3/4" bolts.
- (5) Attach the Front Guard to the outside of the front of the Handles using 4 - 2-1/6" bolts.
- (6) Insert 1 - 3/4" bolt through a Large Washer and through one of the holes at the front of the Tray and attach the top end of a Tray Brace to the Tray. Repeat for the other side. Note: the top of the Tray Brace is the shallow angle which mounts against the Tray, while the bottom of the Tray Brace is the 90° angle which mounts against the Handles.
- (7) Insert 4 - 2-1/6" bolts through the holes in the top of the Handles, note that two of the bolts will go through the bottom end holes of the Tray Braces. Place Axle Plates and Axle Brackets over bolts protruding through bottom of the handles. Loosely tighten each bolt with a washer and nut.
- (8) Slide the Axle through the Axle Brackets, slide a Wheel Spacer, a Wheel and a washer onto each end of the Axle. Secure with a Cotter Pin through hole in Axle. Bend Cotter Pin so it will not fall out.
- (9) Tighten all nuts firmly with a hand wrench or socket (DO NOT over tighten or use power tools for final tightening).